

## Installation guide

# Plant Wall

---

To guarantee an optimal integration of the plant wall into its framework, we slightly reduce the dimensions during manufacturing.

### Artificial plant wall:

We include a safety margin of 2 cm in height and width (meaning 1 cm on each side). This tolerance compensates for the thickness of the artificial moss covering the panels.

### Stabilized plant wall:

We include a safety margin of 0.5 cm in height and width (meaning 0.25 cm on each side). This finer tolerance is perfectly suited to the structure of stabilized plants.

Tanaman —



Unpack your plant wall. It may be delivered in multiple panels (numbered on the back).



Mounting brackets are attached to the back of the wall for easy hanging.



Mark reference points on your wall corresponding to the measurements of the plant wall brackets.



Insert the wall anchor into the wall. Make sure to choose the correct anchor system for your wall type (plaster, concrete...).



Hang your plant wall.